


# LUMIX



# Panasonic

ideas for life




## MEGA O.I.S. (Optical Image Stabilizer): Taking Hand-Shake out of the Picture



## INTELLIGENT ISO CONTROL by Motion Detection: Reducing Blur Caused by Subject Movement

### Zoom shots

Even when using high zoom, which is easily affected by a slight hand-shake, **there's no blurring!!**  
MEGA O.I.S. suppresses hand-shake.



### Night-portraits

Even if you cannot use flash, which would spoil the ambience, **there's no blurring!!**  
MEGA O.I.S. suppresses hand-shake.



### Self-portraits

Even if the shooting position is wobbly, **there's no blurring!!**  
MEGA O.I.S. suppresses hand-shake.




### Macro shots

Even the slightest hand-shake would spoil the picture, **there's no blurring!!**  
MEGA O.I.S. suppresses hand-shake.



### Moving Subject (Outdoor)

Even if you're not ready enough to shoot and the subject is moving fast, **there's no blurring!!**  
Intelligent ISO Control suppresses motion-blur.



### Moving Subject (Indoor)

Even if there is not enough light and the subject is moving around, **there's no blurring!!**  
Intelligent ISO Control suppresses motion-blur.




## From 28mm Wide Angle Providing Shots with Rich Width and Perspective

The wide angle conveys width and depth when shooting landscapes, and it's ideal for shooting group portraits in a small room.



## Up to 12x Powerful Optical Zoom Extending the Zoom Ratio for More Dynamic Close-ups

A 12x optical zoom pulls even distant objects into your range.



DMC-FZ50



DMC-FZ8



DMC-TZ3/TZ2



DMC-LX2



DMC-FX50



DMC-FX30



DMC-FX07



DMC-FX12/FX10



DMC-LZ7/LZ6



DMC-LS75/LS70/LS60



## Optional Accessories

### Tele Conversion Lens

For pulling distant subjects up close

DMW-LT55 (1.7x)



Tele-end setting



With DMW-LT55

### ND Filter

For controlling the exposure to make the shots artistic

DMW-LND52  
DMW-LND55



DMW-LND52



Without ND Filter



With ND Filter


### Close-up Lens

DMW-LC55



### Marine Case

For protecting the camera against water  
(Waterproof to 130ft./40m)



DMW-MCTZ3



DMW-MCFX30  
DMW-MCFX07

### Wide Conversion Lens

For producing a wide view of close subjects

DMW-LW55 (0.7x)



Wide-end setting



With DMW-LW55

### MC Protector

For protecting the lens  
(e.g. in areas with dust or sand)

DMW-LMC52  
DMW-LMC55



DMW-LMC52

### Lens Adaptor

DMW-LA2



### External Flash

DMW-FL500 (GN50)  
DMW-FL360 (GN36)



DMW-FL500

### SDHC/SD Memory Card



\*\*Usable capacity will be less

\*\*SDHC Memory Card can be used only with SDHC equipment.

	FZ50	FZ8	TZ3 TZ2	LX2	FX50	FX30	FX12 FX10	FX07	LZ7 LZ6	LS75 LS60
Battery Pack	CGR-S006		CGA-S007	CGA-S005		DMW-BCE10	CGA-S005		AA OXYRIDE Batteries AA (LR6) Alkaline Batteries AA Ni-MH Rechargeable Batteries	
AC Adaptor	DMW-AC7				DMW-AC5				DMW-AC6	
External Flash	DMW-FL500 DMW-FL360									
Shutter Remote Control	DMW-RS1 DMW-RSL1									
ND Filter	DMW-LND55	DMW-LND52								
Close-up Lens	DMW-LC55	DMW-LC55*								
MC Protector	DMW-LMC55	DMW-LMC52								
Wide Conversion Lens	DMW-LW55	DMW-LW55*								
Tele Conversion Lens	DMW-LT55	DMW-LT55*								
Marine Case			DMW-MCTZ3			DMW-MCFX30	DMW-MCFX07			
Carrying Case	DMW-CZA30 DMW-BAL1	DMW-CZS7 DMW-CHFZ8	DMW-CT3 DMW-CHTZ3	DMW-CLXA1 DMW-CTA1	DMW-CX50	DMW-CX07** DMW-CXA1 DMW-CHF30 DMW-CX12	DMW-CX07** DMW-CXA1 DMW-CHF30 DMW-CX12	DMW-CX07** DMW-CXA1 DMW-CHF30 DMW-CX12	DMW-CLZ5 DMW-CHTZ3	DMW-CLS75 DMW-CHTZ3

\*Lens adaptor DMW-LA2 needed. \*\*Not available in some countries.